



1 Signal setting

After installing the speed signal converter, Please change the relative setting as suggestion.

- The tire circumference : 714
- Sensor point : 6

2 Speed signal converter



3 Wiring installation instructions

