

- 1. This igniter has an automatic recognition function with single hub (Ducati 50 model) and double hub (Piaggio 50cc series 100cc series).
- 2. The external speed limit function cannot be activated if the engine speed is lower than 3500 rpm.

When the engine speed is higher than 3500 rpm, press the red "A" button on the remote control, the cdi enters the speed limit and the speed limit is determined.

By adjusting the small speed setup screw clockwise or counter clockwise the maximum speed increases or decreases.

You have to test several screw positions by driving with full force.

Press the "B" button to cancel the new set speed limiter.

- 3. The item factory-set speed screw is set to 3600-4500 rpm.
- 4. The angle of the double hub is 36 degrees.
- 5. After adjusting the speed limit screw, fix the speed limit screw with nail varnish or wire glue.